Lighting the Heater:

1. Before attempting to light the heater, smell all around the heater area for gas. Be sure to smell next to the floor because LP-Gas is heavier than air and will settle on the floor. Turn on the gas supply to the appliance and check all fittings and connections for gas leaks NEVER use a match to check for gas leaks. Should a gas leak occur, shut off the gas supply to the appliance immediately. Wait a minimum of five minutes before repairing the leak.

2. Use only Liquid Propane for fuel.

3. Turn off the main gas supply to the appliance. Wait five minutes.

4. Turn on the main gas supply.

5. Depress red spark ignition button repeatedly, depress and hold the purple reset button on the safety valve. After the burner ignites, hold the reset button depressed for about one minute or until the burner stays lit when the reset button is released. DO NOT light the gas at the burner orifice. DO NOT face heater when attempting to light. Always stand to the side of the unit when lighting.

NOTE: In cases where long runs of gas supply lines have been installed ahead of the appliance, it may be necessary to bleed trapped air out of the supply lines before lighting the burner. New installations generally require bleeding of supply lines. Wait a minimum of five minutes after bleeding the supply lines before attempting to light the heater.

6. IMPORTANT: DO NOT attempt to adjust the main burner input using the main gas supply valve, for this may cause the thermocouple to shut down the burner.

Shut-down instructions:

To turn the heater OFF:

1. Close the LP-Gas supply cylinder valve.

2. Observe the burner until flame is extinguished.

3. Listen for closure of the safety valve.

4. IMPORTANT: DO NOT re-open the LP-Gas supply cylinder valve before the safety valve closes.