


INSTRUCTIONS

- 1. INTENDED USAGE: Knee kickers should be used for positioning carpet, hooking carpet on tack strip, and light stretching in cramped areas. Use a power stretcher for "stretching-in" rooms, since hard kicking can injure the user and damage the carpet.
- 2. LENGTH ADJUSTMENT: A press of the buttons allows the choice of 4 length adjustments from 21¾" to 25". Always check that both sets of buttons are engaged before beginning your kicking.
- 3. PIN PENETRATION: The pin adjustment dial gives a visual reference showing pin depth. Set the depth to the approximate carpet thickness. In use, the long pins should reach through the pile into the carpet backing, but not through the backing.
- 4. BUMPER PAD ROTATION: The bumper is seamless and is foam-filled. The pad can be turned for an even distribution of wear.

PARTS DIAGRAM



MODEL No. 505

Order No.	Description
1505-01	Bumper & Screws (4)
1505-A2	Head & Tube Assembly
1505-K	Gripper Inserts (3)
1505-Q	Gripper Screws (3)
1505-R	Double Button Spring Clip
1525-11	Bumper Support & Tube Assembly
1601-B	Pin Plate
1601-H	Cover Cap

CRAIN CUTTER CO., INC.  
1155 WRIGLEY WAY  
MILPITAS, CA 95035-5426

PLACE  
STAMP  
HERE